
VGRS (Variable Gear Ratio Steering) System

- General
 - The steering gear ratio will be changed in accordance with the vehicle speed



Major Difference from '05 LX470


Item	'06 GS430	'05 LX470
Rotational Position Sensor (for motor)	Resolver Three Hall ICs	
System Warning	Warning Message	VGRS Warning Light
Communication	CAN, Serial Communication	Serial Communication








System Diagram




Steering Gear Ratio


Confidential




System Operation




- System Operation
 - VGRS ECU adds the supplemental assist with steering speed to reduce delay of vehicle response




VGRS Actuator



- Spiral Cable
 - Flexible flat cable is used



- Lock Mechanism
 - Locks the motor shaft




- Lock Mechanism
 - Lock / unlock operation









- Motor
 - A compact high-output low-noise brush-less motor;




- Reduction Mechanism
 - The strain wave gearing type reduction mechanism



- Reduction Mechanism
 - Components



- Reduction Mechanism
 - Number of teeth



- Reduction Mechanism
 - Construction







Stator Gear


Flexible Gear

Wave Generator

Ball Bearing is between flexible gear and wave generator

View from stator gear side (Steering wheel side)


- Reduction Mechanism
 - Operation of strain wave gearing




- Reduction Mechanism
 - Operation of strain wave gearing



- Reduction Mechanism
 - Operation of strain wave gearing




- Reduction Mechanism
 - Reduction gear ratio



- Operation
 - Vehicle speed is low (quick ratio)



- Operation
 - Vehicle speed is mid. (normal ratio)



- Operation
 - Vehicle speed is high (slow ratio)



- Warning Message
 - VGRS warning message for the system malfunction





- Diagnosis
 - 29 DTCs for VGRS system

DTC	Detection Item		
C1591	VGRS Actuator Neutral Position Calibration Undone		
C1592	VGRS Actuator Neutral Position Calibration Incomplete		
C1593	VGRS Actuator Standard Position Malfunction		
C1595	Lost Communication with Steering Angle Sensor Module		
C1597	Lost Communication between VGRS and EPS		
C15A1	VGRS Actuator Malfunction		
C15A2	VGRS Actuator Malfunction		
C15A3	VGRS Actuator Malfunction		
C15A4	VGRS Actuator Malfunction		
C15A5	VGRS Actuator Malfunction		
C15A6	VGRS Actuator Malfunction		
C15A9	Lock Holder Deviation Detection		
C15AA	Lock Mechanism Release Incomplete		
C15AB	Lock Mechanism Insertion Malfunction		





- Diagnosis
 - 29 DTCs for VGRS system

DTC	Detection Item	
C15B1	VGRS ECU Malfunction	
C15B2	VGRS ECU Malfunction	
C15B3	VGRS ECU Malfunction	
C15B4	VGRS ECU Malfunction	
C15C1	Steering Angle Sensor Malfunction	
C15C2	Steering Angle Sensor B+ Malfunction	
C15C3	Brake System Control Module Malfunction	
C15C6	IG Power Supply Voltage Malfunction	
C15C7	DC Motor Power Source Voltage Malfunction	
C15C8	Power Supply Relay Failure	
U0100	Lost Communication With ECM/PCM "A"	
U0122	Lost Communication With Vehicle Dynamics Control Module	
U0123	Lost Communication With Yaw Rate Sensor Module	
U0126	Lost Communication With Steering Angle Sensor Module	
U0131	Lost Communication With Power Steering Control Module	



Initialization and Calibration

Item	Steering Angle Sensor Initialization	Calibration
Replacement •VGRS ECU •VGRS Actuator	0	0
Repairing steering system parts		
Reconnect the battery terminal		
Reconnect the connectors •Steering Angle Sensor •VGRS ECU •VGRS Actuator •Skid Control ECU	0	*